



NECESSARY ACCESSORIES WITH PIPE PLUG (WITHOUT BY PASS)



NECESSARY ACCESSORIES WITH PIPE TEST PLUG (WITH-BYASS)





NECESSARY ACCESSORIES FOR LEAK TESTING BY WATER



**INFLATABLE PIPE PLUG
MODEL: PTP XXX**



**INFLATABLE PIPE PLUG
MODEL: PP XXX**



**AIR HOSE
MODEL: AH10**




**WATER HOSE
MODEL: WH-10**



**AIR DISCAHRGE ADAPTOR
MODEL: ADA**



AIR SUPPLY SOURCE



MODEL: ACD 0-1.5*

MODEL: SRV 0-10**

CONTROL DEVICE



NECESSARY ACCESSORIES FOR LEAK TESTING BY AIR

